



## FITTING INSTRUCTIONS

### T Bar/Interconnect Connector Kit (Loose) for Powakaddy

1. Find a suitable flat clear surface to work on.
2. Use a small container to keep parts in whilst working.
3. If you have a digital camera, before you start and at each stage take photographs so that you can check back when re-assembling.
4. Prise apart the two halves of the old interconnect plug using a screwdriver or something similar and slide the existing shrink tube back down the cable.
5. If the two contacts need replacing, cut them off and solder or crimp on the two new ones to the wires, remembering to slide the springs up each wire first (Some wires were larger than the holes, if this is so you will need to drill a larger hole in each contact to suit your wire).
6. If the contacts and springs are OK, refit the contacts and springs into one half of the plug. Make sure they are fitted to the correct plus and negative sides.
7. Push the two halves together and fit the two rivets in their holes. Lay the plug on a flat hard surface and punch the pins home.
8. Slide the shrink tube over the top of the plug and hold it down while you apply heat from a hairdryer or electric hot air gun.

Electric Golf Trolley Spares, nor any of its employees, assume no responsibility or liability for any damage or malfunction when a customer carries out self-fitting of this part. Any modification and/or conversion of the item invalidate any guarantee. We will supply telephone or email support if required

Electric Golf Trolley Spares  
08435 23 51 30  
info@lambeggolfshop.com