

22/6/98

## Replacing Flexi Electric Golf Trolley Tyres

### Flexi 24 tyres

To remove the old tyre, unscrew the faceplate and the tyre (two screws in the back of the wheel). Tap the tyre on one side, then the other to break down the adhesive. If you have difficulty in removing the tyres, they can be cut off.

To fit the new tyres, firstly warm in hot water or a low oven. After drying the inside face of the tyres, apply a smear of evostick adhesive and press the tyres onto the wheel hub to the bottom flange of the hub. Screw the tyre on the hub and run the wheel on the axle to ensure the tyre runs true with the wheel before the adhesive sets. If it is slightly "out", it can be corrected by moving the tyre on the hub.

### Flexi 17 tyres (see drawing below)

These tyres are far more difficult to replace.

1. The old tyre will have to be cut off in order to remove.
2. To fit a new tyre to the hub it will be necessary to make a mandrel, and fix it to bench.
3. The tyre should then be warmed and glue applied as with the Flexi: 24.
4. Place the wheel hub onto the mandrel and push the tyre on, as you would fit a tyre to a vehicle wheel.

